

Measuring for Blinds Outside the Reveal

1

Be sure to measure accurately – If the window has a very shallow recess, has mullions or latches obstructing a blinds path, then fitting the blind inside may not be possible or practical. And some blinds, like Romans, are best suited for an outside fit. Correct measurements are important



2

Measure for width – Determine where the blind should be mounted and what it should cover. Generally you'd measure from 'outside of the frame to outside of the frame' for a neat look (wider if you want your blind to cover more space).

Measure at the widest point – if the frame is uneven, or to be safe, measure the width in 2 or 3 places.

Make sure you hold the tape measure level for accurate measuring. Note the **widest** measurement in **millimetres** – this will be the measurement you provide



3

Measure for height – Measure the height ‘outside of the frame to outside of the frame’. Again, in multiple spots if you suspect any irregularities. Make sure you hold the tape measure vertically for accurate measurements. Note the **longest** measurement in **millimetres**, as this will be the one you use



4

Supply measurements as width X drop. Use millimetres (mm) for best accuracy and also provide what window side you'd like the controls: either L (left) or R (right)
State the measurements you've provided are: **Outside Fit**

988 X 1402 R OUTSIDE FIT

