

Installing 25mm Aluminium Venetians

Inside the Reveal

1

Prepare to install – tools which will be helpful are: Screwdriver or power drill with appropriate screwdriver bit, screws (1 per bracket), step ladder (if required), pencil (optional), & tape measure (optional).

Carefully unpack your blinds

2

Fit the brackets – at the desired depth within the reveal – It's more common to install the blinds closer to architrave face than deep in the reveal. About 10mm back from the face looks good. Make sure wherever you do install the blinds will be free of any window or door handles etc when raising or lowering the blind

Each blind width will dictate how many brackets are recommended:

Blind Width: 0m – 1m use 2 brackets

Blind Width: 1m – 2m use 3 brackets

Blind Width: 2m – 3m use 4 brackets

Blind Width: 3m – 4m use 5 brackets

Measure 105mm in from each end of you window for your two end brackets. Screw these in. If your blind requires more than two brackets (as above) place the brackets at even spaces along the blind. A bracket must never be fitted directly above the Control Unit or Ladder cradle – a bracket must be placed between your Control Unit and the first ladder cradle next to it

TIP: you can lie your blind on the window sill or below in a way so you view where the control unit and ladder cradles are within the headrail to assist bracket placement

3

Fitting your blind – Clip the blind headrail into the brackets making sure each bracket clicks, holding the blind securely in place. The wand and control cord are at the front of the headrail, facing into the room. Once secure you can confidently raise, lower and tilt your blind