

Measuring for Blinds Inside the Reveal

1

Be sure to measure accurately – If the window is set in a recess, fitting the blind inside it makes for a neat finish. Avoid mistakes by measuring accurately and taking your time. Measure tight, wood to wood. Don't make your own deductions as the factory does this for you.



2

Measure for width – Measure the width of the recess in three places: at the top, in the middle, and at the bottom. Make sure you hold both ends of the tape measure on the **inside** edges of the recess. Note the **smallest** measurement in **millimetres** – this will be the measurement you use.





3

Measure for height – Measure the height of the window recess in three places: at the left, in the centre, and at the right. Make sure you hold both ends of the tape on the **inside** edges of the recess. Note the **shortest** measurement in **millimetres** – this will be the one you use.





4

Supply measurements as width X drop. Use millimetres (mm) for best accuracy. Provide what window side you'd like the controls on. Either L (LEFT) or R (RIGHT).

E.g. 678 X 1305 R

