

Measuring for Aluminium Blinds, Outside Fit

1

Measure accurately – If your window jamb is shallower than 35 mm, or window handles and latches reduce the available depth, an outside fit may be required. Measure carefully for best results



2

Measure the width – Hold the tape measure level and measure from the '**outside edge of architrave to outside edge of architrave**'. Record the measurement in millimetres (mm)



3

Measure the drop – Hold the tape measure vertically and measure from the '**outside edge of architrave to outside edge of architrave**'. Record the measurement in millimetres (mm)



4

Supply measurements as **WIDTH X DROP**

Use **millimetres** (mm) for best accuracy. Provide the control side which suits best: either L (LEFT) or R (RIGHT)

EG: 678 X 1305, R

