

Measuring for SmartBlock™

Full Inside Fit

1

Be sure to measure accurately – If your window jamb is 86mm or deeper – your SmartBlock™ system including the cassette box will fit completely inside the jamb. Take your time to measure accurately. Measure tight, wood to wood. Don't make deductions – the factory will do that



2

Measure for width – Measure the width of the jamb in three places: right at the top, in the middle, and at the bottom. Make sure you hold both ends of the tape measure on the **inside** edges of the jamb. Note the **smallest width** measured. Provide dimensions in **millimetres (mm)**





3

Measure the drop – Measure the drop of the window jamb in three places: on the left, in the centre, and on the right-hand side. Hold the tape measure vertically **inside** the jamb. Use the **shortest drop** measured – provide drop in millimetres (mm)





4

Supply measurements as **WIDTH X DROP**

Use **millimetres (mm)** for best accuracy. Provide the control side which suits best: either **L (LEFT)** or **R (RIGHT)**

EG: 678 X 1305, R

