

SmartBlock™ Inside & Semi-Inside Fit Installation Guide

Tools Required

- Cordless drill & drill bits
- Phillips screwdriver

Installation Steps

1. Install the Cassette Box

Do not crease or remove the light-block film on both sides. Ensure jamb depth is at least 20mm. Fix cassette using the 32mm screws provided

2. Insert Blind into Cassette

Install control end into the cassette bracket. Press the end plug button and slide into the bracket hole. Lock with bracket pin

3. Install Side Channels

Press lock point and slide safety tensioner to bottom (Chain control option only). Remove paper band and test blind. Clip side channels into cassette end caps. Use U-shaped PVC card to expose screw holes and screw into jamb. Insert bottom channel and secure with screws

4. Attach Cassette Cover

Hook the top edge of the cover onto the cassette, then swing down to lock. For Chain control blinds: ensure the control chain isn't pinched

5. Secure Safety Tension Device (chain control blind option only)

Attach holder to pre-drilled hole with 'TOP' facing up. Press lock point, snap device into place, and ensure chain is taut

Tip: For chain-free or motorised SmartBlock™ blinds, simply skip the chain/tension steps included above

Need a visual guide?

Watch the full SmartBlock™ Inside Fit installation video here:

<https://www.blindsonline.net.nz/faq/smartblock/how-do-i-install-smartblock-blackout-blinds-as-an-inside-fit/>

