

Measuring for PVC Blinds, Outside Fit

1

Measure accurately – If your window jamb is too shallow to comfortably house your pvc blind, or window handles and latches reduce the available depth, an outside fit may be required. Measure carefully for best results



2

Measure the width – Hold the tape measure level and measure from the '**outside edge of architrave to outside edge of architrave**'. Record the measurement in millimetres (mm)



3

Measure the drop – Hold the tape measure vertically and measure from the '**outside edge of architrave to outside edge of architrave**'. Record the measurement in millimetres (mm)



4

Supply measurements as **WIDTH X DROP**

Use **millimetres** (mm) for best accuracy. Provide the control side which suits best: either L (LEFT) or R (RIGHT)

EG: 678 X 1305, R

