

Measuring for Roller Blinds

Outside Fit ON Architrave

1

Measuring for Roller Blinds – When it comes to outside fitting roller blinds there are two main approaches. One way is to mount them on the architrave itself. The other approach is to mount them above the architrave on the wall. These instructions outline **'outside fit ON architrave'**



2

Measure for width – If your architraves are flat (and 40mm or wider) mounting your roller blinds on them makes for an easier install compared with mounting them on the wall above the architrave. The architrave should be flat and the back of the bracket flush with the edge of the architrave. The edge of the fabric is then about 16mm in from each side of the architrave. Architraves of 40mm or wider suit this approach. We want enough width in the architraves, so the fabric edge overlaps the jamb and runs down the architrave. For those super skinny architraves (30mm or narrower), I would recommend mounting 'outside fit ABOVE architrave'

Measure from '**outside edge of architrave**' on one side to '**outside edge of architrave**' on the other side. Hold the tape measure level and provide the width in **millimetres**



3

Measure the drop – Measure from ‘outside edge of architrave’ at the top to ‘outside edge of architrave’ at the bottom of the window. If it’s a full-length window or door, then measure to the floor. Make sure you hold the tape measure vertically and provide your drop in **millimetres**



4

Supply measurements as **WIDTH X DROP**

Use **millimetres** (mm) for best accuracy. Provide the control side which suits best: either L (LEFT) or R (RIGHT)

EG: 878 X 1505, R

