

Measuring for Honeycomb Blinds Outside Fit ON Architrave

1

Be sure to measure accurately – Fitting honeycomb blinds inside the jamb makes most sense thermally. However, if you have very shallow jambs, or mullions, or handles, etc, obstructing the blind's path then fitting the honeycomb blind outside the jamb may be required



2

Measure for width – Determine where the blind should be mounted and what it should cover. For the most part measure from **'outside edge of architrave to outside edge of architrave'** for an easy to install, neat finish

Hold the tape measure level for accurate measuring.
Provide measurements in **millimetres**



3

Measure the drop – Measure the drop 'outside edge of architrave to outside edge of architrave'. Make sure you are holding the tape measure vertically for accurate measurements – provide drop in **millimetres**



4

Supply measurements as **WIDTH X DROP**

Use **millimetres** (mm) for best accuracy. Provide the control side which suits best: either L (LEFT) or R (RIGHT)

EG: 878 X 1505, R

